

I Want A "Hard Copy"



* Copy quality will depend on your photocopier.

Preserving Your Design

Now that you've spent all those minutes (or seconds) on your room furniture plan, and you want to keep a copy of it for future reference, preserving the layout is as easy as turning on a photocopier. In fact that is the first step. The second step is to gently place the layout board containing your floor plan face-down onto the copier and press the START button. Pretty easy, huh? The result is a high-quality copy*.

The layout board is comprised of blue grid lines scaled $1/4" = 1'-0"$. When copying your layout, you can control the visibility of these lines by adjusting the darkness setting - darker for increased visibility, lighter for removing the lines. Having the lines visible can come in handy if when copying your design, you want to reduce or enlarge the copy output and wish to quickly calculate sizes or dimensions. Simply count the squares. Regardless of whether you have increased or decreased the size of your layout, the squares will always equal 1 sq. ft.

Maintaining The Board™

Put The Magnetic Symbols Back!

Keep The Layout Board Clean

Temperature

Care & Maintenance

Under normal conditions you should enjoy many years of space planning creativity with *The Board™*. Remembering a few simple tips for care of your system will help ensure that you always get the most from using the system.

One of the features of the planning system is the ease-of-use in keeping the magnetic symbols organized. On the binder pages, we have printed an exact copy of the magnetic symbol in GREEN, to easily identify symbols which are in use. This was done to simplify the replacement of symbols in *The Board™* binder when you are finished with them. A quick check of the pages to see if there is any "green" showing will go a long way to making sure that none of the symbols go missing. (Replacement parts are available, if needed).

The layout board is laminated with a plastic film to allow you to use any water-soluble markers directly on the board (i.e. to draw walls, doors, notes, etc.). Any marks can be easily cleaned by using a damp cloth, or paper towel. A household window cleaner could also be used periodically to remove any marks that a damp cloth does not get.

DO NOT USE PERMANENT MARKERS ON THESE ITEMS.
No markers should be used on the magnetic symbols themselves as even a wet-erase marker will permanently stain the symbols.

As with any vinyl product, *The Board™* may be susceptible to low temperatures (near freezing, 32 deg. F, or 0 deg. C). If you work in a climate where temperatures can get quite low, and are in the habit of keeping your planning system in your car, it would be advisable to let the binder warm up to room temperature for a few minutes prior to opening it up. This will prevent the binder from "cold-cracking".

Warranty

With the exception of the wet-erase marker, all components of *The Board™* Space Planning Systems are covered by a **Limited 1 Year Warranty** against defects in materials and / or workmanship. Masterplan Magnetics Inc. will repair or replace any or all of the components at their discretion, (customer pays shipping). No other warranty is expressed or implied.